


Servo 1234



Level 2

Modules: Servo Motor

- Wildcards
- Events



| | | |
|--|--|--|
| when 1 ▼ key pressed set servo to 10 %: Connector A ▼ | when 2 ▼ key pressed set servo to 20 %: Connector A ▼ | when 3 ▼ key pressed set servo to 30 %: Connector A ▼ |
| when 4 ▼ key pressed set servo to 40 %: Connector A ▼ | when 5 ▼ key pressed set servo to 50 %: Connector A ▼ | when 6 ▼ key pressed set servo to 60 %: Connector A ▼ |
| when 7 ▼ key pressed set servo to 70 %: Connector A ▼ | when 8 ▼ key pressed set servo to 80 %: Connector A ▼ | when 9 ▼ key pressed set servo to 90 %: Connector A ▼ |